MENS / WOMENS AND JUNIOR STYLES AVAILABLE

SPANDEX CARE INSTRUCTIONS

TAKE CARE WASHING

Heatenething

Hamma stield

0

RINSE IN FRESH WATER AFTER USE. DO NOT DRY OR LEAVE IN DIRECT SUNLIGHT. WATER TEMP AT 30 C OR BELOW HANG AND DRY INSIDE OUT DO NOT IRON **OTHER CARE** KEEP VELCRO HOOKS AWAY FROM LINING OR STITCHING. IIGH TEMPERATURES. CHEMICALS AND OILS IN SUNSCREENS CAN DAMAGE FABRIC INSPECT YOUR GEAR REGULARLY FOR ANY EARLY SIGNS OF WEAR OR DAMAGE.

WWW.ZHIK.COM

SUPERMENT

Ched soft Alayernation

Solume So

Refer to product swing tag when selling to customer

THE COMPLETE SET

the medical solution

SPANDET

South the the Outobe solder with

Hondo Contraction

HORONOR

0

CHOOSE THE TOPS TO BEST SUIT YOUR CONDITIONS

HIGH QUALITY MATERIALS